

Heat Pump

Exhaust valve

Water Outlet

Copper connection

Water Inlet

